

Modern Rail 3/4" Installation Guide

Please note: We strongly recommend hiring a local professional drapery installer to ensure a perfect outcome!

Components:



**CEILING MOUNT
BRACKET**



**CEILING MOUNT
BRACKET / SPLICE**



WALL MOUNT SPLICE



**WALL MOUNT
BRACKET**



MODERN TRACK



END STOP/END LOCK



PLEATED CARRIERS



RIPPLEFOLD GLIDES

Installation of Ceiling Mount Modern Rail 3/4"

1 Your drapery is slightly larger than your rods as we make the drapery with ease for better opening and closing. Your finished pole size is noted on your packing slip (do not use finished width size on drapery bundle). Measure 4" to 6" in from each end of the track and mark the placement of the bracket on the ceiling. We recommend placing the brackets 24" to 36" apart across the width of the track. Heavy drapery requires the brackets to be placed closer together.

2 Once the spacing of the brackets has been determined, measure out from the wall 3" for placement of the screw in the back of the bracket (this placement is personal preference but if you have ripplefold drapery the centre of your track it must be more than 2.5" for the drape to clear the wall). Drill a hole for the screw to determine if you require a plug. If so, add your plug and continue the same process for each bracket.

**Keep in mind the projection of the trim and the sill, if there is one. The bracket may have to be placed out further to clear these.*

3 Place the brackets onto the top rail of the track by sliding the bracket onto the rail. Slide the required number of brackets onto the track and tighten by pinching the metal bracket just enough so the bracket will still move slightly.

4 Count your drapery hooks or snaps in the case of ripplefold. Slide the same number of glides as hooks or snaps into the bottom channel of track. Before adding your last glide/snap, place the last glide/snap into your endcap and slide it into the track.

Note: a glide or snap is placed on the outer side of the end cap to anchor the drapery — see photos.



5 You are now ready to attach the track to the ceiling. Lifting the track with the brackets on it to the ceiling, screw the screws into the pre-drilled holes/plugs and tighten. This will require 2 people in most cases.

6 The drapery can now be hung on the track.

Installation of Wall Mounted Modern Rail 3/4"

- 1 See note in Step 1 for ceiling mount track regarding drapery/rod width. Measure 4" to 6" in from each end of the track and mark the placement of the bracket on the ceiling. We recommend placing the brackets 24" to 36" apart across the width of the track. Heavy drapery requires the brackets to be placed closer together.
- 2 Using the bracket, follow the chart below to calculate height placement of brackets (the measurement below is to the top of the bracket). Mark the screw placement on the wall and pre-drill holes based on your previous widths marked. Use appropriate plugs for your wall type where necessary to hold the bracket firmly on the wall. Attach the bracket to the wall and place cover plate over the base to hide the screws.

	RIPPLEFOLD	PLEATED
To clear the floor ¼"	Finished length +2"	Finished length +1"
To kiss the floor	Finished length +1.75"	Finished length +.75"
To break on the floor ½"	Finished length +1.25"	Finished length +.25"

- 3 You are now ready to lift the track to the brackets post on the wall. Lift the track and tighten the set screws on the bracket. This step will most likely require a second person.
- 4 Add the glides and end stops to the bottom of the rail. Add end caps to the ends and you are ready to hang the drapery.